



Replace keyboard

Written By: Felice Suglia





TOOLS:

- [Phillips #0 Screwdriver](#) (1)
-

Step 1 — accumulator




- Open the latch of the battery on the right side.
- Open the latch of the battery on the left side.
- Remove the battery.

Step 2 — keyboard






- Press gently on the first clip so that the cover strip with the ON / OFF button can be removed.
- Press gently on the second clip so that the cover strip with the ON / OFF button can be removed.
- And so on.

Step 3



- Then turn to the laptop and rid the Cover strip.
- The four keyboard attachment screws are now visible.
- Solve this now fixing bolts.

Step 4



- Get rid slowly the keyboard.
- You will return them to.
- Now remove the keyboard cable.

Step 5



- Once the plug cable is disconnected, lift the keyboard out carefully.

Um das Gerät wieder zusammen zu bauen gehen Sie in umgekehrter Reihenfolge vor.

This document was last generated on 2017-06-20 08:41:48 AM.